



SIZING: EMS AND TECHNICAL RESCUE JACKET AND PANT

Step 1 - Take the measurements as outlined for the jacket and or pant (reference pages 2 and 3 for details)

Step 2 - Select Jacket Size - The jacket size will be determined by two factors:

First - Your Measurements!

If your Chest measurement is larger than your Hip or Waist measurement, use your Chest measurement to choose a size from the chart below.

If your Hip or Waist measurement is larger than your Chest measurement, use the Hip/Waist measurement to select your jacket size from the chart below.

Second - Take into consideration what you will be wearing UNDER the jacket:

If you are purchasing a warmth liner with this jacket, select one size larger than your measurement dictates.

If you plan to wear a sweatshirt under the jacket, select one size larger than your measurement dictates.

Step 3 - Select Jacket Sleeve Length

The standard sleeve length for each size jacket is on the chart

If your sleeve length is more than 2" SHORTER than the regular, select a SHORT

If your sleeve length is more than 2" LONGER than the regular, select a TALL

Step 4 - Select a Waist Size

Use the larger of your waist measurement or hip measurement and select the waist size for the pant based on this measurement.

Ricochet's pants have either an elastic waist or waist tab adjustments, so select a size larger if you have any concern about fit

Step 5 - Select an inseam Size

Use the measurements for your inseam to select an inseam

If your inseam is more than 2" SHORTER than the Regular, select a SHORT

If your inseam is more than 2" LONGER than the regular, select a TALL


JACKET SIZING					
Ricochet Size	Your Chest Measurement	Standard Back Length	Sleeve Options		
			Short	Regular	Tall
Small	34-36	28	32	34	36
Medium	38-40	29	33	35	37
Large	42-44	30	34	36	38
X-Large	46-48	31	35	37	39
2X-Large	50-52	32	36	38	40
3X-Large	54-56	32	37	39	41
4 X-Large	58-60	32	37	39	41
5X-Large	62-64	32	37	39	41

PANT SIZING				
Ricochet Waist Size	Your Waist Measurement	Inseam Options		
		Short	Regular	Tall
Small	Under 32	28	30	32
Medium	32-36	28	30	32
Large	36-40	28	30	32
X-Large	40-44	28	30	32
2X-Large	44-48	28	30	32
3X-Large	48-52	28	30	32
4 X-Large	52-56	28	30	32
5X-Large	56-60	28	30	32



RICOCHET SIZING INFORMATION

Proper sizing is extremely important for the safety of the user. For that reason, Ricochet offers two sizing methods, sizing gear and/or measurements. In both cases, accuracy is very important. The following list of measurements is necessary for both men's and women's garments. Use a high quality non-stretch tape, holding it straight and snug so that it lies smooth without indenting the body. (Always start with the low end of numbers.)





Ricochet Sizing Information

JACKETS

CHEST:

Measure loosely over clothing around the fullest part of the chest/bust. Have firefighter take and hold a deep breath. Arms should be at rest by their sides. Both an under-the-arm and over-the-arm measurement should be taken at the widest part of the chest/bust. Over-the-arm measurements are extremely important for individuals with broad shoulders and muscular arms and/or backs.

SLEEVE:

Ricochet's standard sleeve lengths are designed and graded proportionately to chest sizes, which will fit the majority of firefighters. However, for shorter or longer arm lengths, with arms at rest straight down to side, measure from the base of the neck (the C-5 vertebra) over the shoulder and down the arm to the base of the thumb (about 1" below the wrist bone).

PANTS

WAIST:

Measure around waist over any clothing or accessories that would be normally worn under your turnout pants.

INSEAM:

Standard inseam lengths are available in one inch increments. Inseam length should be shorter than regular pant inseam to prevent damage to cuffs. Measure from the crotch down the inside of the leg to the bottom of the ankle bone.

HIPS (Female Only):

Measure around the fullest part of the hip area.